




## Installation Quick Start Guide for AQT-F2 Important Installation Instructions

- 1** Remove old filter by unscrewing housing. Insert the new element into the housing as described in the user manual which accompanied the refrigerator at the time of purchase.
- 2** Condition the filtering system by running water through the dispenser for 3 minutes before using.
- 3** Reset the "replace filter" light. Refer to your refrigerator owner's manual for reset procedure.
- 4** Attach the included water filter replacement calendar label according to the label instructions.



**For further questions or assistance please call (866) 218-8473.  
Monday - Friday 8am to 5pm Pacific Standard Time**

### WARNING

A newly-installed water filter cartridge may cause water to spurt from the dispenser until all the air is removed. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

Protect from freezing.

To reduce the risk of property damage due to water leakage, this filter **MUST** be installed in accordance with the manufacturer's specifications and instructions. This filter must be replaced every 6 months, at the rated capacity, or sooner if reduced water flow occurs. Failure to follow instructions and operation specifications will void your warranty. Further, manufacturer assumes no responsibility or liability for damages arising out of misuse of the product. The filter bypass plug **MUST** be used when a filter replacement cartridge is not installed.

The risk associated with small parts can cause choking if swallowed. Keep children away from small parts during the replacement of the water filter.