



## Installation Quick Start Guide for AQT-F7

### Important Installation Instructions

---

- 1** Press the button to the right of the filter to release from mounting head.
- 2** Remove the old filter by pulling straight out.
- 3** Push the new filter in firmly until seated into the mounted head; you will hear a "Click" once it is in place.
- 4** If the filter does not "Click" into place, remove and try again. It may take more force than expected.
- 5** Once seated correctly, flush 3 gallons of water from the dispenser to remove any loose fines and to prime the filter.  
NOTE: Initial flow rate may be slower than expected.  
Full flow rate should be restored within 24-36 hours.
- 6** To reset Filter Indicator Light, press and hold the reset button on the dispenser until the green light flashes (up to 15 seconds).

**For further questions or assistance please call (866) 218-8473.  
Monday - Friday 8am to 5pm Pacific Standard Time**

#### **WARNING**

A newly-installed water filter cartridge may cause water to spurt from the dispenser until all the air is removed. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.

Protect from freezing.

To reduce the risk of property damage due to water leakage, this filter **MUST** be installed in accordance with the manufacturer's specifications and instructions. This filter must be replaced every 6 months, at the rated capacity, or sooner if reduced water flow occurs. Failure to follow instructions and operation specifications will void your warranty. Further, manufacturer assumes no responsibility or liability for damages arising out of misuse of the product. The filter bypass plug **MUST** be used when a filter replacement cartridge is not installed.

The risk associated with small parts can cause choking if swallowed. Keep children away from small parts during the replacement of the water filter.